



Suitable Cables: Semi-rigid .085

This part number complies with RoHS.

Notice: JYEBAO reserves the right to make modifications deemed appropriate.



CABLE ASSEMBLY INSTRUCTION K3300-0085 JYE BAO CO., LTD. В Α **CONTACT PIN BODY** ASSEMBLY INSTRUCTION DIAGRAM Step 1: STRIP AS SHOWN. 2.5 [.098] Step 2: PUT 0.24 MM GAGE IN PLACE, INSERT CABLE'S CENTER CONDUCTOR INTO CENTER PIN " B " AND SOLDER IN " Y ". 0.24 GAGE Step 3: INSERT PREPARED CABLE INTO CONNECTOR BODY " A " AND USE SOLDERING FIXTURE " ST-008 ", INSERT TOOL " ST-009 " AND LOCATOR TOOL " ST-011 " TO FIX THE CONNECTOR. SOLDER IN " X ". ST-008

This part number complies with RoHS.

Notice: JYEBAO reserves the right to make modifications deemed appropriate.