

6. Melody

Device	Standard Type	Song List	Time Base (KHz)	Electrical Characteristic			Package	Remark
				V _{DD} (V)	I _{DD} (μ A)			
					Stand-by	Operating		
KS531/ KS5321	KS531/KS5321A KS531/KS5321B †KS531/KS5321C †KS531/KS5321D †KS531/KS5321E †KS531/KS5321F †KS531/KS5321G †KS531/KS5321H †KS531/KS5321I †KS531/KS5321J	Symphony, #9 'choral' 4th Mov(Beethoven) Chime(Ding Dong Sound) Symphony #40(Mozart) Toy symphony(Haydn) Do Re Mi Song It's a small world A small fountain Pong Dang Pong Dang Oh! Brenery Die Forelle	125	15 (3.0)	0.5 (max)	0.5mA	Chip 8 DIP (KS5321) TO-92L (KS531)	Speaker drive Digital ENV built in Dual tone
KS537/ KS5327	KS537/KS5327A KS537/KS5327B KS537/KS5327C KS537/KS5327D KS537/KS5327E KS537/KS5327F KS537/KS5327G KS537/KS5327H KS537/KS5327I KS537/KS5327J KS537/KS5327K KS537/KS5327L KS537/KS5327M KS537/KS5327N KS537/KS5327O † KS537/KS5327U	Jingle bells For elise Happy birthday to you Home sweet home Cuckoo's waltz Westminster Mary had a little lamb Choral symphony oh, susanna Music box dancer Love me tender, love me true Arirang Green sleeves Twinkle twinkle little star Hand in hand Our wish	65	15 (3.0)	0.1	15	Chip 8 DIP (KS5327) TO-92 (KS537)	Speaker or piezo drive
KS5328	KS5328A	For elise A maiden's prayer	65	1.5 (3.0)	0.5 (max)	50	Chip 16 DIP	LED drive END/BUSY signal output -Dual tone
	KS5328B	Romance de Amor Petrouchka						
KS5381	KS5381A	Home sweet home Oh, susanna Whispering hope Dreaming of home and mother Oh, my darling elementire Beautiful Dreamer Red river vally	32.768	1.5 (3.0)	0.1	200 (min)	Chip 16 DIP 20 DIP	For watch IC 16 DIP: serial selection 20 DIP: binary selection
KS5401	Electronic soun effect		125	3	0.5	100	Chip, 18 DIP	Speaker
KS5814	Sky-lark and circket sound		210	1.5	0.1	250	Chip, 14 DIP	Speaker

† New Product †† Under Development