



LCD-S4X1C35TR



PIN NO.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
SEGMENT	COM	Y	Z	DP1	1E	1D	1C	DP2	2E	2D	2C	DP3	3E	3D	3C	DP4	4E	4D	4C	4B
PIN NO.	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
SEGMENT	4A	4F	4G	3B	3A	3F	3G	COL2	2B	2A	2F	2G	COL1	1B	1A	1F	1G	←	X	COM

LCD-S4X1C43TR



PIN NO.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
SEGMENT	1F	1A	1B	2F	2A	2B	3F	3A	3B	4F	4A	4B	COM1	/	/
SEGMENT	1E	1G	1C	2E	2G	2C	3E	3G	3C	4E	4G	4C	/	COM2	/
SEGMENT	DP1	1D	L	DP2	2D	X	DP3	3D	LO BAT	DP4	4D	CONT	/	/	COM3