# Image sensor heads for Card-compatible IA2002-CE10A

ROHM s IA2002-CE10A contact image sensor head utilizes a special ceramic substrate featuring superior dimensional precision and thermal dissipation characteristics, resulting in stable reading, even under fluctuating ambient temperature conditions. A unique prism, developed using the latest in optical technology, ensures simultaneous uniform light output and low light radiation to the media. In addition, bidirectional reading capability enables greater flexibility regarding carrier orientation.


#### Applications

Image scanners (i.e. business card), detection sets (e.g. surface, paper edge, paper type)

#### Features

- 1) 25in/s (635mm/s) read speed (monochrome)
- 2) Bidirectional reading capability
- 3) 54mm read width (70mm total width)
- 4) Color light source (switchable)

#### ●Dimensions (Unit: mm)



ROHM

#### ● Characteristics

Parameter	Symbol	Тур.	Unit
Effective scanning width	-	54	mm
Primary scan dot density	-	200	dpi
Total dot number	-	432	dots
Power supply voltage	VDD	3.3	V
Scanning speed	SLT	0.2×3	ms / line
Clock frequency	CLK	4	MHz
Maximum dynamic range (VDD=5V)	VRMax.	0.5	V
Minimum dynamic range (VDD=5V)	VRMin.	0.25	V
Maximum dynamic range (VDD=3.3V)	VRMax.	0.4	V
Minimum dynamic range (VDD=3.3V)	VRMin.	0.2	V
Dark output (VDD=5V)	Vod	1.2±0.4	V
Dark output (VDD=3.3V)	Vod	0.8±0.4	V
Operating temperature	_	5 to 45	°C


## ●Pin assignments

No.	Circuit	1/0	Functions	
1	CLK	I	Clock	
2	SP	I	Start Pulse	
3	V <sub>DD</sub>	I	Power Supply	
4	GND	I	Ground	
5	Ao	0	Analog Output	
6	RLED	I	LED ground	
7	GLED	I	LED ground	
8	BLED	I	LED ground	
9	VLED	I	LED power supply	

Rev.A


### Timing chart

## (a) CLK Timing Chart




## (b) Data Output Timing Chart

After turning on the SP pulse, the analog output shape starts from the setting up point of 65 clock pulse.




Note) Output blank part cannot be used as the analog output standard level.

#### ●Equivalent circuit



#### Peripheral circuit



\* R1=R2=100Ω C1=47μF, C2=100pF C3=100μF, C4=0.1μF

\* Please adjust the value of resistance to fit your interface circuit.

#### Notes

- No technical content pages of this document may be reproduced in any form or transmitted by any
  means without prior permission of ROHM CO.,LTD.
- The contents described herein are subject to change without notice. The specifications for the
  product described in this document are for reference only. Upon actual use, therefore, please request
  that specifications to be separately delivered.
- Application circuit diagrams and circuit constants contained herein are shown as examples of standard
  use and operation. Please pay careful attention to the peripheral conditions when designing circuits
  and deciding upon circuit constants in the set.
- Any data, including, but not limited to application circuit diagrams information, described herein are intended only as illustrations of such devices and not as the specifications for such devices. ROHM CO.,LTD. disclaims any warranty that any use of such devices shall be free from infringement of any third party's intellectual property rights or other proprietary rights, and further, assumes no liability of whatsoever nature in the event of any such infringement, or arising from or connected with or related to the use of such devices.
- Upon the sale of any such devices, other than for buyer's right to use such devices itself, resell or
  otherwise dispose of the same, no express or implied right or license to practice or commercially
  exploit any intellectual property rights or other proprietary rights owned or controlled by
- ROHM CO., LTD. is granted to any such buyer.
- Products listed in this document are no antiradiation design.

The products listed in this document are designed to be used with ordinary electronic equipment or devices (such as audio visual equipment, office-automation equipment, communications devices, electrical appliances and electronic toys).

Should you intend to use these products with equipment or devices which require an extremely high level of reliability and the malfunction of which would directly endanger human life (such as medical instruments, transportation equipment, aerospace machinery, nuclear-reactor controllers, fuel controllers and other safety devices), please be sure to consult with our sales representative in advance.

It is our top priority to supply products with the utmost quality and reliability. However, there is always a chance of failure due to unexpected factors. Therefore, please take into account the derating characteristics and allow for sufficient safety features, such as extra margin, anti-flammability, and fail-safe measures when designing in order to prevent possible accidents that may result in bodily harm or fire caused by component failure. ROHM cannot be held responsible for any damages arising from the use of the products under conditions out of the range of the specifications or due to non-compliance with the NOTES specified in this catalog.

Thank you for your accessing to ROHM product informations.

More detail product informations and catalogs are available, please contact your nearest sales office.

**ROHM** Customer Support System

THE AMERICAS / EUROPE / ASIA / JAPAN

www.rohm.com

Contact us : webmaster@rohm.co.jp

Copyright © 2008 ROHM CO.,LTD.

ROHM CO., LTD. 21 Saiin Mizosaki-cho, Ukyo-ku, Kyoto 615-8585, Japan

pan TEL:+81-75-311-2121 FAX:+81-75-315-0172

