

FME3100W-0316	FME Plug Crimp	50Ω															
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 20%;">Parts</th> <th style="width: 20%;">Material</th> <th style="width: 60%;">Plating(Micro-inch)</th> </tr> </thead> <tbody> <tr> <td>Ferrule</td> <td>Brass</td> <td>Tin-Zinc-Copper-Alloy 100 over Copper 50</td> </tr> <tr> <td>Contact Pin</td> <td>Brass</td> <td>Gold 3 Over Nickel 50 Over Copper 50</td> </tr> <tr> <td>Insulator</td> <td>Teflon</td> <td></td> </tr> <tr> <td>Body</td> <td>Brass</td> <td>Tin-Zinc-Copper-Alloy 100 over Copper 50</td> </tr> </tbody> </table>			Parts	Material	Plating(Micro-inch)	Ferrule	Brass	Tin-Zinc-Copper-Alloy 100 over Copper 50	Contact Pin	Brass	Gold 3 Over Nickel 50 Over Copper 50	Insulator	Teflon		Body	Brass	Tin-Zinc-Copper-Alloy 100 over Copper 50
Parts	Material	Plating(Micro-inch)															
Ferrule	Brass	Tin-Zinc-Copper-Alloy 100 over Copper 50															
Contact Pin	Brass	Gold 3 Over Nickel 50 Over Copper 50															
Insulator	Teflon																
Body	Brass	Tin-Zinc-Copper-Alloy 100 over Copper 50															
<p>Weight: 4.99 g Suitable Cables: RG174, RG188, RG316, RG316-E, RG316-FEP</p>																	

This part number complies with RoHS.

Notice: JYEBAO reserves the right to make modifications deemed appropriate.

CABLE ASSEMBLY INSTRUCTION

FME3100W-0316

JYE BAO CO., LTD.








DIAGRAM	ASSEMBLY INSTRUCTION
	<p>Step 1: STRIP AS SHOWN .</p>
	<p>Step 2: SLIDE FERRULE " C " OVER CABLE . Step 3: PUT CONTACT PIN " B " ON CENTER CONDUCTOR AND CRIMP IN " Y " .</p>
	<p>Step 4: LOOSEN BRAIDING AND SLIDE CONNECTOR " A " IN PLACE .</p>
	<p>Step 5: SLIDE FERRULE " C " TOWARDS THE CONNECTOR " A " AND CRIMP .</p>

This part number complies with RoHS.

Notice: JYEBAO reserves the right to make modifications deemed appropriate.