

<h3 style="text-align: center; margin: 0;">0489</h3> <p>0489-X-15-XX-11-XX-04-0 Press-fit in .041 mounting hole.</p>	<table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Basic Part Number</th> <th style="text-align: left;">Length A</th> </tr> </thead> <tbody> <tr> <td>0489-0</td> <td>.102</td> </tr> <tr> <td>0489-1</td> <td>.199</td> </tr> <tr> <td>0489-2</td> <td>.299</td> </tr> </tbody> </table>	Basic Part Number	Length A	0489-0	.102	0489-1	.199	0489-2	.299	<h3 style="text-align: center; margin: 0;">0463</h3> <p>0463-0-15-XX-21-XX-04-0 Press-fit in .043 mounting hole. shell is Phos. Br. Alloy 544 (B2)</p>	<h3 style="text-align: center; margin: 0;">0466</h3> <p>0466-0-15-XX-21-XX-04-0 Press-fit in .043 mounting hole. shell is Phos. Br. Alloy 544 (B2)</p>
Basic Part Number	Length A										
0489-0	.102										
0489-1	.199										
0489-2	.299										

<h3 style="text-align: center; margin: 0;">7491</h3> <p>7491-0-15-XX-X1-XX-04-0 Press-fit in .042 mounting hole</p>	<h3 style="text-align: center; margin: 0;">0462</h3> <p>0462-0-15-XX-X1-XX-04-0 Press-fit in .043 mounting hole</p>	<h3 style="text-align: center; margin: 0;">0560</h3> <p>0560-0-15-XX-11-XX-10-0 Hex press-fit in .043 plated thru hole</p>	
--	--	---	--



<p>SPECIFICATIONS</p> <p>SHELL MATERIAL: Brass Alloy 360, 1/2 Hard</p> <p>CONTACT MATERIAL: Beryllium Copper Alloy 172, HT</p> <p>DIMENSION IN INCHES TOLERANCES ON: LENGTHS: ±.005 DIAMETERS: ±.002 ANGLES: ± 2°</p>	<p>ORDER CODE: XXXX - X - 15 - XX - XX - XX - XX - 0</p> <p>BASIC PART # </p> <p>SPECIFY SHELL FINISH: </p> <p>01 200m " TIN/LEAD OVER NICKEL 15 10m " GOLD OVER NICKEL</p> <p>SPECIFY CONTACT FINISH: </p> <p>02 200m " TIN/LEAD OVER NICKEL 14 10m " GOLD OVER NICKEL 27 30m " GOLD OVER NICKEL</p> <p align="center">SELECT CONTACT #11 or #21 CONTACT (DATA ON PAGE 206)</p>	
--	--	--