

## General Purpose Rectifiers

TYPE NO.	$V_{RRM}$ (V)	$I_O$ (A)	$T_A$ (°C)	$I_{FSM}$ (A)	$I_{RRM}$ ( $\mu$ A)	$V_{FM}$ (V)	$I_F$ (A)	CASE
IN 4001	50	1.0	75	30	10	1.1	1	DO-41
IN 4002	100	1.0	75	30	10	1.1	1	DO-41
IN 4003	200	1.0	75	30	10	1.1	1	DO-41
IN 4004	400	1.0	75	30	10	1.1	1	DO-41
IN 4005	600	1.0	75	30	10	1.1	1	DO-41
IN 4006	800	1.0	75	30	10	1.1	1	DO-41
IN 4007	1000	1.0	75	30	10	1.1	1	DO-41
IN 5391	50	1.5	40	50	10	1.4	1.5	DO-15
IN 5392	100	1.5	40	50	10	1.4	1.5	DO-15
IN 5393	200	1.5	40	50	10	1.4	1.5	DO-15
IN 5394	300	1.5	40	50	10	1.4	1.5	DO-15
IN 5395	400	1.5	40	50	10	1.4	1.5	DO-15
IN 5396	500	1.5	40	50	10	1.4	1.5	DO-15
IN 5397	600	1.5	40	50	10	1.4	1.5	DO-15
IN 5398	800	1.5	40	50	10	1.4	1.5	DO-15
IN 5399	1000	1.5	40	50	10	1.4	1.5	DO-15
IN 5400	50	3.0	50	150	10	1.2	3	DO-201AD
IN 5401	100	3.0	50	150	10	1.2	3	DO-201AD
IN 5402	200	3.0	50	150	10	1.2	3	DO-201AD
IN 5403	300	3.0	50	150	10	1.2	3	DO-201AD
IN 5404	400	3.0	50	150	10	1.2	3	DO-201AD
IN 5405	500	3.0	50	150	10	1.2	3	DO-201AD
IN 5406	600	3.0	50	150	10	1.2	3	DO-201AD
IN 5407	800	3.0	50	150	10	1.2	3	DO-201AD
IN 5408	1000	3.0	50	150	10	1.2	3	DO-201AD
R 250-A	50	6.0	60	400	10	1.1	10	4
R 250-B	100	6.0	60	400	10	1.1	10	4
R 250-D	200	6.0	60	400	10	1.1	10	4
R 250-F	300	6.0	60	400	10	1.1	10	4
R 250-H	400	6.0	60	400	10	1.1	10	4
R 250-K	500	6.0	60	400	10	1.1	10	4
R 250-M	600	6.0	60	400	10	1.1	10	4
R 250-P	700	6.0	60	400	10	1.1	10	4
R 250-S	800	6.0	60	400	10	1.1	10	4
R 250L-A	50	6.0	60	250	25	1.0	6	5
R 250L-B	100	6.0	60	250	25	1.0	6	5
R 250L-D	200	6.0	60	250	25	1.0	6	5
R 250L-F	300	6.0	60	250	25	1.0	6	5
R 250L-H	400	6.0	60	250	25	1.0	6	5
R 250L-K	500	6.0	60	250	25	1.0	6	5
R 250L-M	600	6.0	60	250	25	1.0	6	5
R 250L-P	700	6.0	60	250	25	1.0	6	5
R 250L-S	800	6.0	60	250	25	1.0	6	5