

## Narrowband Fiber Optic Coupler 980 nm, 90:10 Ratio



### Description


Thorlabs' TN980R2A2B single mode narrowband fiber coupler is designed for a center wavelength of 980 nm with  $\leq 0.2$  dB of excess loss within the specified bandwidth.

### Specifications


| TN980R2A2B   |   |
|--|---|
| Coupling Ratio <sup>a</sup>                          | 90:10   |
| Coupling Ratio Tolerance                             | $\pm 2.0\%$   |
| Center Wavelength                                    | 980 nm  |
| Bandwidth <sup>a,b</sup>                             | $\pm 15$ nm   |
| Excess Loss <sup>a</sup>                             | $\leq 0.2$ dB   |
| Insertion Loss <sup>a</sup>                          | $\leq 0.8$ dB / $\leq 11.2$ dB  |
| Polarization-Dependent Loss (PDL) <sup>a</sup>       | $\leq 0.2$ dB   |
| Optical Return Loss (ORL) / Directivity <sup>a</sup> | $\geq 60$ dB  |
| Max Power Level <sup>c</sup>                         | 1 W (With Connectors or Bare Fiber)<br>5 W (Spliced)                        |
| Fiber Type <sup>d</sup>                              | HI1060 FLEX   |
| Fiber NA   | 0.22  |
| Fiber Cut-Off Wavelength <sup>b</sup>                | $930 \pm 40$ nm   |
| Port Configuration                                   | 2x2   |
| Fiber Lead Length and Tolerance                      | 0.8 m $+0.075$ m / $-0.0$ m   |
| Connectors   | 2.0 mm Narrow Key FC/APC  |
| Package Size   | $\varnothing 0.12'' \times 2.76''$ ( $\varnothing 3.2$ mm $\times$ 70.0 mm) |
| Jacket   | $\varnothing 900$ $\mu$ m Hytrel <sup>®</sup> Loose Tube                    |
| Pigtail Tensile Load                                 | 10 N  |
| Operating Temperature Range                          | $-40$ to $85$ °C  |
| Storage Temperature Range                            | $-40$ to $85$ °C  |



- All values are specified at room temperature over the bandwidth without connectors and measured through the white input port as indicated below; similar performance ( $\leq 0.05$  dB difference) is achieved when the blue port is used as the input.
- Below the cut-off wavelength, single mode operation is not guaranteed (see the graph on the following page).
- Specifies the total maximum power allowed through the component. Coupler performance and reliability under high-power conditions must be determined within the user's setup. See Usage Tips for safety and handling information.
- Other fiber types may be available upon request. Please contact [techsupport@thorlabs.com](mailto:techsupport@thorlabs.com) with inquiries.



## Performance Data



This plot shows the coupling ratio performance of four TN980R2A2B couplers (tap and signal outputs from the same coupler are indicated by matching colors on each graph). The blue- and red-shaded regions denote the coupler's full operating wavelength range. Please note that the red region indicates wavelengths for which the coupler operation may become multimode. All data was measured without connectors.

## Usage Tips

- 1) Before connecting a component to a system, make sure the light source is turned off. Inspect both the input and output fiber ends; debris or contamination on the end face can lead to fiber damage when operated at high powers.
- 2) After connecting the component, the system should be tested and aligned using a light source at low power. The system power can be ramped up slowly to the desired output power while periodically verifying all components are properly aligned and that coupling efficiency is not changing with respect to optical launch power.
- 3) Optical connectors can be removed and the device can be spliced into a setup for operation at higher optical powers. Fiber ends should always be cleaned and cleaved prior to splicing.